



QUV (and QCT) Space Saver Frames

QUV® space saver frames from Q-Lab help preserve space in crowded labs with multiple QUV test chambers. By allowing two QUV testers to be stacked, floor space efficiency is maximized.

Features and Benefits

- Saves valuable floorspace in crowded labs
- Anodized aluminum construction resists corrosion
- Compact design to allow for easy access to both units
- Leveling feet for uneven surfaces
- Two models for compatibility with all new and existing QUV testers
- Optional extended door handle, allowing for easier vertical opening and closing of the top unit.



Stacking testers on the space saver frame allows easy access to both machines.

Description

Space saver frames are designed in two models for compatibility with virtually any combination of new and existing QUV testers. QCT testers on space saver frames require factory installation. Heavy-duty, anodized aluminum construction helps the space saver frame resist corrosion and keep its appearance identical to the QUV units. Leveling feet permit secure installation on uneven floor surfaces.

Model Types, Dimensions, and Shipping Weight

QUV space saver frames are available in two different models (Note: see instructions on next page to find the correct model).





Model	Compact	Standard		
Compatible with QUV testers ¹	New & Retrofit Series 81+	New and Retrofit Series 1-80		
Plumbing	Fully integrated	External ²		
Compatible with QCT testers	No	Contact Q-Lab		
Dimensions (h x w x d)	184 x 127 x 62 cm (72.5 x 50 x 24.5 in)	202 x 127 x 62 cm (79.5 x 50 x 24.5 in)		
Required Water Input/Drains	One Water Input One Drain	Two Water Inputs Two Drains		
Weight	34 kg (75 lb.)	34 kg (75 lb.)		

- 1. Transformer kits (V-149-K, V-149.1-K) cannot be installed on Compact Space Saver Frame. Contact Q-Lab for options to install on the Standard Space Saver Frame.
- 2. Spray models require additional external plumbing boxes.
- 3. Extreme Environment Air Filter Kits (V-60284-K, V-60304-K, V-60304-K-INST, V-60306-K, V-60307-K) cannot be installed on either Space Saver Frame. Contact Q-Lab for details.

Instructions For Identifying The Correct Space Saver Frame Part Number

1. Select the appropriate space saver frame letter designation (A, B, C, D, E) from the Space Saver Frame Compatibility Matrix below by identifying the desired bottom and top configuration of your QUV (or QCT) testers.

2. Using the letter from Step 1, select the appropriate part number(s) in the Part Number Identification Table.

Space Saver Frame Compatibility Matrix

Bottom Unit	New QUV/basic, QUV/se, QUV/cw	New QUV/spray¹	New QUV/spray w/ standalone REPUR ^{1,2}	Retrofit Series 81+ QUV/basic, QUV/se, QUV/cw	Retrofit Series 81+ QUV/spray¹	Retrofit Series 81+ QUV/spray/REPUR ^{1,2}	New or Retrofit Series 81+ QUV/uvc	Retrofit Series 1-80 QUV/basic, QUV/se	Retrofit Series 1-80 QUV/spray¹	Retrofit Series 1-80 QUV/spray/REPUR ^{1,2}	New QCT5
New QUV/basic, QUV/se, QUV/cw	Α	-	_	Α	-	ı	D	D	ı	-	
New QUV/spray	В	В	_	В	В	ı	D	D	D	_	
New QUV/spray w/standalone REPUR		ı	Α	Α	-	Α	D	D	ı	D	
Retrofit Series 81+ QUV/basic, QUV/se, QUV/cw	ı	_	_	С	ı	-	D	D	-	-	Contact Q-Lab⁴
Retrofit Series 81+ QUV/spray	C³	_	_	С	С	_	D	D	D	_	Ğ
Retrofit Series 81+ QUV/spray/REPUR ²	C³	_	-	С	_	С	D	D	_	D	tact
New or Retrofit Series 81+ QUV/uvc	D	_	_	D	_	-	D	D	_	_	Son
Retrofit Series 1-80 QUV/basic, QUV/se, QUV/cw	D	_	_	D	_	_	D	D	_	_	
Retrofit Series 1-80 QUV/spray	D³	D	_	D	D	-	D	D	D	-	
Retrofit Series 1-80 QUV/spray/REPUR ²	D³	_		D	_	D	D	D	_	D	
New QCT	Contact Q-Lab										

- 1. If there is only one QUV/spray unit, it should always be the bottom unit on the space saver frame.
- 2. Requires purchase of a standalone repurification system. Integrated repurification system cannot be reused.
- 3. For field retrofits of QUV/spray units with a new non-spray unit, consult Q-Lab.
- 4. For Space Savers with a 1x QUV and 1x QCT, consult Q-Lab.

Part Number Identification Table

	Α	В	С	D		E	
Model	Compact			Standard			
Space Saver Frame	V-60227-K-INST	V-60228-K-INST	V-60229-K	V-440-K-INST for New, V-440-K for Retrofit1			
New QUV/spray only Bottom Plumbing Box ² Top Plumbing Box ²	-	ı	ı	120V V-60171-K-INST V-60172-K-INST	230V V-60173-K-INST V-60174-K-INST	-	
Existing QUV/spray only Bottom Plumbing Box ² Top Plumbing Box ²	ı	ı	ı	120V V-2428-K V-2429-K	230V V-2440-K V-2441-K	ı	

- 1. Field Retrofits are not available for QCT. Contact Q-Lab for options.
- 2. Plumbing boxes or standalone repurification systems are required for each QUV/spray tester used in configuration D.

Warranty

For important warranty information, visit Q-Lab.com/Warranty.



For sales, technical, or repair support, please visit:

Q-Lab.com/support

Westlake, Ohio USA • Homestead, Florida USA • Wittmann, Arizona USA Bolton, England • Saarbrücken, Germany • Shanghai, China